



PGC Assembly Guide

Steps

Picture Guides

1. Attach Gun Cable into port A



2. Attach Grounding Cable Assembly behind Grounding Nut



3. Attach Power Cable to back of PGC and tighten Screw to secure. (Do not plug into Wall outlet until setup is complete)



4. Attach Rinsing Air Assembly into 1.4 Fitting



5. Attach Other End of Rinsing Air Tubing onto Barb Fitting Bottom of Gun Handle



6. Attach Black Supplemental Air into 1.3 Fitting



7. Attach Red
Conveying Air into
1.2 Fitting



8. Attach other ends
of Supplemental &
Conveying Air to
Powder Pump



9. Attach Fluidization
Assembly into 1.1
Fitting



10. Attach Regulator
End of Fluidization
Assembly to Quick
Disconnect On
Powder Hopper



11. Attach Powder
Pump to Powder
Hopper Pickup
Tube



12. Attach Powder
Hose Securely to
Powder Hose
Pump Connector



13. Attach other end
of Powder Hose to
Gun

